About This Guide

This preface has information under the following headings:

- Audience
- Document Organization
- Related Publications
- Document Conventions
- Cisco Connection Online

Audience

This book is intended for anyone who installs, manages, and configures a Cisco 6200 advanced digital subscriber line access multiplexer (DSLAM).

Document Organization

This book provides task-based instructions for installing and using the Cisco 6200 Manager to configure, manage, and monitor a Cisco 6200 DSLAM.

The manual is organized as follows:

- Chapter 1, "Cisco 6200 Manager Overview," describes the Cisco 6200 Java-based element management application that you can use to configure and manage the Cisco 6200 DSLAM.

- Chapter 2, "Getting Started," contains platform and system requirements and provides instructions for installing the Cisco 6200 Manager application.

- Chapter 3, "Managing the Manager," tells how to start and administer the Cisco 6200 Manager as well as use its help system.

- Chapter 4, "Configuring with the Manager," provides information about using the Cisco 6200 Manager to configure the Cisco 6200 DSLAM.

- Chapter 5, "Monitoring and Testing," explains how to use the Cisco 6200 Manager to check the status of the Cisco 6200 DSLAM, its cards, and its ports. The chapter also includes procedures for testing lines.

- Appendix A, "Glossary," defines some of the terms and acronyms mentioned in this book.

Related Publications

The following documents are relevant to Cisco 6200 users:

- *Cisco 6200 FRU Installation and Replacement*

  Tells you how to install and remove Cisco 6200 field-replaceable units (FRUs)

- *Cisco 6200 User Guide*

  Includes an overview of the Cisco 6200, installation instructions, hardware information, troubleshooting guidelines, and documentation of the IOS command line interface (CLI).

- *Cisco 675 Installation and Operation Manual*

  Explains how to install and operate the Cisco 675 (SpeedRunner 204) ADSL modem

- *Cisco CO POTS Splitter Installation Guide*

  Explains how to install the plain old telephone service (POTS) splitter for the Central Office (CO)

- *NID POTS Splitter Installation* and *Tabletop/Wall-Mount POTS Splitter Installation*

  Explain how to install the POTS splitters for customer premises equipment such as the Cisco 675

- *Release Notes for the Cisco 6200 for Cisco IOS Release 11.3(1)DA2*

  Describes the features of and caveats for the Cisco 6200 advanced DSLAM

- *Release Notes for the Cisco 6200 Manager Release 1.0*

  Describes the features of and caveats for the Cisco 6200 Manager software application

Document Conventions

The following conventions are used in the *Cisco 6200 Manager User Guide*:

- **Boldface** is used for buttons and submenu names.

- If items such as buttons or menu options are grayed out on application windows, they are not currently available.

Note   Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this manual.

The term *server* is used to refer to the Cisco 6200 Manager server, and the term *element* is used to refer to a card or port.

Cisco Connection Online

Cisco Connection Online (CCO) is Cisco Systems' primary, real-time support channel. Maintenance customers and partners can self-register on CCO to obtain additional information and services.

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to Cisco's customers and business partners. CCO services include product information, product documentation, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously: a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, and Internet e-mail, and it is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: http://www.cisco.com

- WWW: http://www-europe.cisco.com

- WWW: http://www-china.cisco.com

- Telnet: cco.cisco.com

- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and connection rates up to 28.8 kbps.

For a copy of CCO's Frequently Asked Questions (FAQ), contact cco-help@cisco.com. For additional information, contact cco-team@cisco.com.

If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com. To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.