

# Deinstalling the EISA SCO Adapter Software

---

At some point you may want to deinstall the EISA SCO adapter software, for example, if you want to remove the adapter from a workstation. Deinstallation of the adapter software is separated into two steps:

- Using the netconfig utility to remove the chain in the kernel
- Using the custom configuration utility to remove the drivers

Both procedures are discussed in detail in the following sections.

## Using the Netconfig Utility to Remove the Chain

To remove the chain in the kernel:

**Step 1** Log in as superuser.

## Using the Netconfig Utility to Remove the Chain

---

**Step 2** At the command line, start the netconfig utility by entering **netconfig** and pressing **<Return>**. The following screen appears:

```
Currently configured chains:
  1. nfs->sco_tcp
      nfs          SCO NFS Runtime System for SCO Unix
      sco_tcp      SCO TCP/IP for UNIX
  2. sco_tcp->lo0
      sco_tcp      SCO TCP/IP for UNIX
      lo0          SCO TCP/IP Loopback driver
  3. sco_tcp->fddi0
      sco_tcp      SCO TCP/IP for UNIX
      fddi0        CISCO FDDI driver, board 0

Available options:
  1. Add a chain
  2. Remove a chain
  3. Reconfigure an element in a chain
  q. Quit
Select option: 3
```

**Step 3** To remove a chain, enter **3** at the Select option prompt. The following screen appears:

```
Currently configured chains:
  1. nfs->sco_tcp
      nfs          SCO NFS Runtime System for SCO Unix
      sco_tcp      SCO TCP/IP for UNIX
  2. sco_tcp->lo0
      sco_tcp      SCO TCP/IP for UNIX
      lo0          SCO TCP/IP Loopback driver
  3. sco_tcp->fddi0
      sco_tcp      SCO TCP/IP for UNIX
      fddi0        CISCO FDDI driver, board 0
Select a chain to remove ('q' to quit): 3
```

**Step 4** At the Select a chain prompt, select the number corresponding to `sco_tcp->fddi0` chain (in this example, **3** the number of the `sco_tcp->fddi0` chain).

---

**Note** The numbers corresponding to the chain and fddi on your system may differ from those shown in this example.

---

## Using the Netconfig Utility to Remove the Chain

---

The following screen appears:

```
Remove sco_tcp->fddi0 (y/n) : y
```

**Step 5** At the confirmation prompt enter **y**. The following screen appears:

```
Removing sco_tcp->fddi0
Removing fddi0...
irq= slot=
```

Currently configured chains:

```
1. nfs->sco_tcp
   nfs          SCO NFS Runtime System for SCO Unix
   sco_tcp      SCO TCP/IP for UNIX
2. sco_tcp->lo0
   sco_tcp      SCO TCP/IP for UNIX
   lo0         SCO TCP/IP Loopback driver
```

Available options:

```
1. Add a chain
2. Remove a chain
3. Reconfigure an element in a chain
q. Quit
```

Select option: **q**

The current configuration appears without the sco\_tcp->fddi0 chain.

**Step 6** To quit, enter **q** at the prompt. The following screen appears:

```
Do you want to relink the kernel now? y
```

## Using the Netconfig Utility to Remove the Chain

---

**Step 7** To relink the kernel, enter **y** at the prompt. The following screen appears:

```
The UNIX Operating System will now be rebuilt.  
This will take a few minutes. Please wait.
```

```
Root for this system build is /.
```

```
The UNIX Kernel has been rebuilt.
```

```
Do you want this kernel to boot by default? (y/n) y
```

**Step 8** To have this kernel boot by default, enter **y**. The following screen appears:

```
Backing up /unix to /unix.old  
Installing new /unix
```

```
The kernel environment includes device node files and /etc/inittab.  
The new kernel may require changes to /etc/inittab or device nodes.
```

```
Do you want the kernel environment rebuilt? (y/n) y
```

**Step 9** To have the kernel environment rebuilt, enter **y**. The following screen appears:

```
The kernel has been successfully linked and installed.  
To activate it, reboot your system.
```

```
Setting up new kernel environment
```

```
#
```

When the command line prompt reappears, the netconfig utility is complete. To remove the adapter files, continue with the following section.

## Using the Custom Utility to Remove the EISA SCO Adapter Driver Files

Use the SCO Custom configuration utility to remove the SCO adapter driver files.

**Step 1** At the command line, enter the **custom** command and press <Return> as in the following example:

```
# custom
```

The initial SCO sysadmin custom screen appears (similar to Figure A-1), listing the currently installed products.

## Using the Custom Utility to Remove the EISA SCO Adapter Driver Files

---

**Figure A-1** Initial Custom Screen

```
Custom
Install Remove List Quit
Remove

/ Wednesday, November 16, 1994 8:36

----- Products Currently Installed -----
SCO Open Server Enterprise System
Adaptec AIC-7770 Driver for SCO UNIX System
Cisco fddi/cddi Driver
SCO MPX Multiprocessing
NET382C Enhanced TCP/IP 1.2.1 Drivers
SCO Open Systems Software Release 3.0 Release Supplement


H2961
```

To select an item from the menu line, use the movement keys to highlight the item or enter the first letter of the item and press **<Return>**.

- Step 2** From the initial custom screen, select **Remove**. A screen similar to Figure A-2 appears displaying existing drivers.

## Using the Custom Utility to Remove the EISA SCO Adapter Driver Files


**Figure A-2 Existing Driver Screen**



- Step 3** From the lower area of the screen display, select **Cisco fddi/cddi Driver**. The driver selected appears next to the Select a product prompt in the upper area of the screen display. A screen similar to Figure A-3 appears.

## Using the Custom Utility to Remove the EISA SCO Adapter Driver Files


**Figure A-3** Select Part of Product Screen



- Step 4** From the list of options shown in the Cisco fddi/cddi Driver menu, select the default, **All**. A confirmation prompt similar to Figure A-4 appears.



**Figure A-4** Driver Removal Confirmation Screen



**Step 5** At the Do you want to continue prompt, select **Yes**.

Wait while the system deletes the driver files. A screen similar to Figure A-5 appears listing the drivers still installed.

## Using the Custom Utility to Remove the EISA SCO Adapter Driver Files

---

**Figure A-5** Custom Utility Initial Screen

```
Custom
Install Remove List Quit
Quit
/                                     Wednesday, November 16, 1994 8:36
----- Products Currently Installed -----
SCO Open Server Enterprise System
Adaptec AIC-7770 Driver for SCO UNIX System
SCO MPX Multiprocessing
NET382C Enhanced TCP/IP 1.2.1 Drivers
SCO Open Systems Software Release 3.0 Release Supplement
H2966
```

**Step 6** To return to the command line, select **Quit** from the menu line. The following confirmation screen appears.

## Using the Custom Utility to Remove the EISA SCO Adapter Driver Files

---

**Figure A-6 Custom Utility Confirmation Screen**

```
Custom
Yes No
Exit Custom?

/ Wednesday, November 16, 1994 8:36

Products Currently Installed

SCO Open Server Enterprise System
Adaptec AIC-7770 Driver for SCO UNIX System
SCO MPX Multiprocessing
NET382C Enhanced TCP/IP 1.2.1 Drivers
SCO Open Systems Software Release 3.0 Release Supplement
```

H2965

**Step 7** To return to the command line, select **Yes** from the menu line.  
That completes the deinstallation process.

## Using the Custom Utility to Remove the EISA SCO Adapter Driver Files

---